



## Rustic Solid 100 Oil

### GENERAL DESCRIPTION

For professional and private use.

An indoor oil product for untreated/sanded wooden floors and table-/worktops. The oil is practically free from organic solvents.

Choose colour to see package sizes.

---

### PRODUCT DESCRIPTION

**Product:**

Alkyd made from natural drying oils.

**Appearance:**

Gives the wood a deep, warm glow.

---

#### TECHNICAL DATA

**Coverage:** Absorbing wood species: approx. 7.5 m<sup>2</sup> per litre. Less absorbing wood species: approx. 15 m<sup>2</sup> per litre.

**Before application:** Shake/stir well before use.

**Application tools:**

Shorthaired roller in a medium thick layer.

**Substrate temperature:** Minimum 15° C.

**Dilution:** Delivered ready for use. Dilution is not recommended.

**Drying time at 20° C and 50 % RH :**

Minimum 16 hours.

Ready for use 24 hours after the finishing treatment.

Fully cured after 3 days.

Do not cover the surface by i.e. carpets or rugs before the oil is fully cured.

**Cleaning of tools:** White spirit

**Storage:** Lasts for 2 years if unopened and stored at 20° C. Once opened the product will start to form a skin and harden in the can.

---

#### SYSTEM RECOMMENDATIONS

**All areas:**

1 or 2 coats Junckers Rustic Solid 100 Oil

+ 16 hours drying time

+ 1 coat Junckers Rustic TopOil

+ 30-60 minutes drying time

+ 1 coat Junckers Rustic TopOil

The frequency of treatment with Junckers Rustic TopOil depends on wear of the floor. The more traffic the higher frequency of treatment.

---

## DIRECTION FOR USE

### Before application, untreated/sanded wood:

Ensure that the surface is absolutely clean, dry and free from dust, wax, grease, polish etc. Unevenness, dirt and discolouration can be removed by sanding in direction of the grain. Final sanding must be with sandpaper grit 100-120. Vacuum sanding dust.

### Priming of non-absorbing or less absorbing wood species, e.g. oak, ash, merbau:

A single layer of oil is sufficient. Apply oil and leave to dry for approximately 20 minutes.

If spots with rapidly absorbed oil are noticed, then distribute surplus oil over these absorbing areas. Remove any surplus oil with a dry cotton cloth or with help of a polishing machine. Surplus oil must be removed no later than 1 hour after application and the surface should then appear mat and even.

Allow to dry for at least 16 hours, after which wood fibres that have risen should be removed by sanding with a polishing machine equipped with a black pad. Remove sanding dust with a vacuum cleaner.

### Priming of absorbing wood species, e.g. beech and maple:

Apply 1 coat of oil and leave to dry for approximately 20 minutes. Then follow up with a further "wet in wet" coat of oil. Again leave to dry for 20 minutes.

Then proceed as described above.

### Finishing with Junckers Rustic TopOil:

Apply 2 thin coats of Junckers Rustic TopOil (60-80 m<sup>2</sup> per litre per coat), conducted 1 hour apart. The surface is ready for light traffic after approximately 1 hour.

---

## PRECAUTIONARY MEASURES

Before use of the product, read the label on the container carefully and observe the advised precautionary safety measures.

---

## FURTHER INFORMATION

### Products:

F 2.7 - Junckers Rustic TopOil