



## PreLak, Water-based

### GENERAL DESCRIPTION

For professional and private use.

One-component water-based primer Minimises side-bonding for all wooden floors. PreLak dries quickly and is easy to sand. PreLak can be used with Junckers 1-pack and 2-pack water-based finishes.

Choose colour to see package sizes.

### PRODUCT DESCRIPTION

**Product:** Water-based acrylic primer

**Appearance:** Clear: Creamy/milky. Dries up to a colourless film. White: Creamy/milky. Dries up to a transparent white film.

#### TECHNICAL DATA

**Coverage:** 8 m<sup>2</sup> per litre.

**Before application:** Shake well before use.

**Application tools:** Short hair roller. Do not apply by spraying. Don't apply by pouring out the lacquer directly on the floor.

**Substrate temperature:** Minimum 15° C and maximum 25° C.

**Dilution:** Delivered ready for use. Dilution is not recommended.

**Drying time at 20° C and 50 % RH :**  
Approx. 1-2 hours.

**RH:** Water-based products have a certain gluing effect and are therefore only recommended to be used in rooms with a stable humidity. The difference between highest and lowest RH must not fluctuate more than 30 % during the year.

**Cleaning of tools:** Soap and water immediately after use

**Storage:** Lasts for 1 year if unopened and stored at 20° C. Not to be exposed to temperatures below 5° C.

---

#### SYSTEM RECOMMENDATIONS

Junckers PreLak Clear: 1 coat, 8 m<sup>2</sup>/litre or  
Junckers PreLak, White: 2 or more coats, 8 m<sup>2</sup>/liter.  
+ 2 coats of a top-lacquer. Choose according to expected wear of the floor.

**High traffic areas:**

Finish with 2 coats of Junckers Strong, Strong Premium or HP Commercial 10 m<sup>2</sup>/litre.

**Low traffic areas:**

Finish with 2 coats of Junckers ProFinish 10 m<sup>2</sup>/litre.

**Sport areas:**

Finish with 2 coats of Junckers HP Sport 10-12 m<sup>2</sup>/litre

---

## DIRECTION FOR USE

### Untreated/sanded floors:

The surface should be clean, dry and free from dust, wax, grease, polish etc.. Machine sand the surface to remove dirt and irregularities. Vacuum thoroughly and wipe off with a cloth well wrung in clean water.

The final sanding, before applying Junckers PreLak should be carried out by using sandpaper grit 120-150.

### PreLak, Clear:

Apply 1 coat of PreLak Clear in an even layer and leave to dry according to recommendation.

### PreLak, White:

Apply 2 or more coats of PreLak White in an even layer. Make sure that overlapping edges on the lacquered area do not dry out during treatment. Between each coat, leave to dry according to recommendation. Do not apply more than 2 coats per day. Each additional coat of Junckers PreLak White will add more colour to the floor.

When the primer is dry, sand with sandpaper grit 150-180 or a black screening pad. Then finish with 2 coats of one of Junckers recommended floor lacquers.

### Previously sealed floors:

Machine sand before applying Junckers PreLak. Use sandpaper grit 24-36 to strip previous coats. Then remove abrasion marks with sandpaper grit 60-80.

Finally, use sandpaper grit 120-150 to obtain a completely smooth surface.

Vacuum sanding dust and wipe off with a cloth well wrung in clean water. Prime the floor as described under "Untreated/ sanded floors".

---

## PRECAUTIONARY MEASURES

Before using the product, read the label on the container carefully and observe the recommended precautionary measures. See Material Safety Data Sheet for detailed information.

---

## FURTHER INFORMATION

### Products:

- F 4.2 - Junckers ProFinish
- F 5.1 - Junckers Strong
- F 5.9 - Junckers Strong Premium
- F 8.2 - Junckers HP Sport
- F 8.5 - Junckers HP Commercial